



FastWall Sliding Window

Code: FWSW1208

Installation Guide

(Install as wall is built)

Required Components

- FWJ213 - FastWall Jamb - 3 each x 2.13m lengths
- Aluminum corner stakes - 4 each x 30mm
- Perspex - 1200mm x 800mm x 4.5mm thick - 1 each
- Aluminum angle - 4 each x @ 20mm x 12mm x 1.6mm x 1.25m lengths
- Undercut self tapping screws zinc plated 8g x 12mm - 10 each
- Aluminum steel blind rivet 3.2mm x 15mm - 20 each

1. Cut mitres to the FWJ to make a frame with the overall external dimensions of 895mm high x 1270mm wide.
2. Assemble the frame using the corner stakes provided, and rivet together - use the 3mm rivets.
3. Determine the position of the window in the wall, and build the wall up to one side of the window. (Easiest to start the window against a full panel).
4. Cut + Install the four FastWall panels from the floor to window sill level.
5. Slide the window frame over the bottom FastWall panels and over the side panel.
6. Cut + install the four FastWall panels above the top of the window.
7. Continue building the wall, sliding the next full panel into the side of the window frame.
8. Screw fix the window frame to the panels if required.
9. Cut four pieces of the 20 x 12 aluminum angle - 2 for the bottom, 2 for the top.
10. Cut the Perspex into 2 pieces, allowing an overlap in the middle.
11. Install the Perspex as shown in the picture, securing the long leg of the 1st angle to the t&b of the window frame using the counter sunk screws. Secure the short leg of the 2nd angle using the rivets.



Please Note- Refer to the Fastwall Floor to Ceiling Installation Guide for instructions on building Fastwall hoardings.

