



FastWall Window

Code: FWW1208

Installation Guide

(Install as wall is built)

Required Components

- FWJ213 – FastWall Jamb – 3 lengths
 - Aluminum corner stakes – 4 each
 - Perspex – 1175mm x 800mm x 4.5mm thick – 1 each
 - 20 x 12 Aluminum angle – 2 lengths at 2.1m
 - Aluminium white rivets – 3.2mm x 13.6mm – 27 each
1. Cut mitres to the FastWall Jamb to make a frame with the overall external dimensions of 895mm high x 1270mm wide.
 2. Assemble the frame using the corner stakes provided, and rivet together.
 3. Determine the position of the window in the wall, and build the wall up to one side of the window (easiest to start the window against a full panel).
 4. Cut and install the 4 FastWall panels from the floor to window sill level.
 5. Slide the window frame over the bottom FastWall panels and over the side panel.
 6. Cut and install the 4 FastWall above the top of the window.
 7. Continue building the wall, sliding the next full panel into the side of the window frame.
 8. Screw fix the window frame to the panels if required.
 9. Cut the Perspex panel to fit into the window frame, allowing 2-3mm clearance.
 10. Cut mitres to the 20 x 12 aluminum angle.
 11. Position the perspex and secure with the angles, riveting or screwing the angles into position.

Please Note – Refer to the FastWall Floor to Ceiling Installation Guide for instructions on building FastWall hoardings.

