



FastWall Window Installation Guide

(Installed as the window is built)

Components Supplied:

- FWJ213 - FastWall Jamb - 3 lengths
- Aluminum corner stakes - 4of
- Perspex - 1175mm x 800mm x 4.5mmthk - 1of
- 20x12 Aluminum angle - 2 lengths at 2.1m

1. Cut mitres to the FWJ to make a frame with the overall external dimensions of 895mm high x 1270mm wide.
2. Assemble the frame using the corner stakes provided, and rivet together.
3. Determine the position of the window in the wall, and build the wall up to one side of the window. (Easiest to start the window against a full panel).
4. Cut + Install the 4 FastWall panels from the floor to window sill level.
5. Slide the window frame over the bottom FastWall panels and over the side panel.
6. Cut + install the 4 FastWall above the top of the window.
7. Continue building the wall, sliding the next full panel into the side of the window frame.
8. Screw fix the window frame to the panels if required.
9. Cut mitres to the 20 x 12 aluminum angle.
10. Position the perspex + secure with the angles, riveting or screwing the angles into position.

PLEASE NOTE:

Refer to the FastWall Floor to Ceiling Installation Guide for instructions on building FastWall hoardings.

