



HoardFast Window

HFW1208

Installation Guide

(Install as wall is built)

Required Components

- EDJ-23 - Hoardfast Jamb - 2 lengths
- Aluminum corner stakes - 4 each
- Perspex - 1200mm x 800mm x 4.5mm thick - 1 each
- 20 x 12 Aluminum angle - 2 lengths at 2.16m
- Aluminium white rivets - 3.2mm x 13.6mm - 27 each

1. Cut mitres to the EDJ to make a frame with the overall external dimensions of 935mm high x 1136mm wide for the freestanding system, or 935mm high x 1160mm wide for the floor to ceiling system.
2. Assemble the frame using the corner stakes provided, and rivet together.
3. Determine the position of the window in the wall, and build the wall up to one side of the window.
4. Cut and Install the Hoardfast panel from the floor to window sill level.
5. Slide the window frame over the bottom Hoardfast panel and up to the joiner.
6. Cut and install the Hoardfast panel above the top of the window.
7. Continue building the wall.
8. Screw fix the window frame to the panels if required.
9. Cut mitres to the 20 x 12 aluminum angle.
10. Cut the perspex panel to fit into the window frame, allowing 2-3mm clearance.
11. Position the perspex and secure with the angles, riveting or screwing the angles into position.

Please Note - Refer to the Hoardfast Installation Guides for instructions on building Hoardfast hoardings.

