









Protecta Tack Mat

Setup & Usage Guide

Kit Includes

• 1 x Protecta Tack Mat- 30 Sheets

Instructions

- Pull the yellow tab to remove the backing and expose the tacky base for securing to the surface.
- 2. Position the product in the desired location.
- 3. Peel off the top protective film to reveal sticky layer #30.
- 4. Once the layer becomes dirty or full, remove it by pulling the next numbered tab to expose a fresh layer.





Recommended Step

Use a reusable Tack Mat Base (PMB63 or PMB94) to provide a semi-fixed, stable platform for the tack mat sheets. This ensures a rigid foundation and improves overall system performance.



