

RHINO BOARD

INSTALLATION INSTRUCTIONS

CODE # RBMT930 (MEDIUM)
AND RBST930 (SUPER)



- 1** If Rhino Board is to be laid over carpet, it can be held in place by taping the joins. If additional restraint is required, Velcro or Hook tape (HT5025-BK) strips can be used.
- 2** If Rhino Board is to be laid over a prefinished hard surface that has cured, a polyfoam underlay (PF11 or PF21) is advised to prevent the risk of 'scuffing'.
- 3** If Rhino Board is to be laid over a prefinished hard floor that is still curing, a breathable membrane such as BPF161 is recommended.
- 4** Roll out the Rhino Board, cutting to length with a sharp knife where required. The last metre can be rolled back on itself to ensure it sits flat on the floor.
- 5** Tape the joins with Rhino Board tape. (RBT72.)
- 6** Rhino Board is perforated along the edges to allow it to be folded up against a wall or skirting, if required.
- 7** If securing the Rhino Board to a hard floor at the perimeter is required, starting in a corner, roll out STP-100 tape, and then tape the edge of the Rhino Board to this.
- 8** Clean up any spills in a timely manner.
- 9** If Rhino Board is to be reused, ensure the surface is cleaned prior to rolling up.

PROTECTA
IGROUP
TEMPORARY PROTECTION SOLUTIONS

ZERO DUST ■
ZERO DAMAGE
ZERO DEFECTS